



## Quick Start



- USB3.0 streaming output
- 4CH HDMI inputs
- 2" TFT display on board to Live preview four inputs
- Auto cut and manual switch (T-Bar)
- 14 transition effects on T-Bar
- Support PIP (Picture-In-Picture)
- Audio offers embedded or external source to select
- Support switch between 6-Picture PVW and PGM to HDMI Out
- Advanced features on mini+
  - ◎ Logo
  - ◎ Chroma Key
  - ◎ PTZ control
- Control by PC or mobile phone (via APP)
- Compact design

# CONTENTS


Product Introduction.....	2
Packing Configuration.....	3
Hardware Orientation.....	4
Front Panel.....	4
Interface Panel.....	5
Use Your Product.....	6
MENU.....	6
Input.....	6
HDMI.....	7
USB3.0.....	7
Audio.....	7
IP Setting.....	8
LANGUAGE.....	8
Factory Reset.....	8
INFO.....	9
S Button.....	9
MIX.....	9
MODE.....	10
PIP.....	10
FX [mini+ only].....	10
How to Switch Between Input Sources.....	11
How to Apply a PIP.....	11
Software Operation.....	12
OBS Streaming.....	24
OBS Setting.....	24
Streaming Setting.....	26
Upgrade.....	28
Contact Information.....	34



# Product Introduction

mini/mini+ is a “mini” signal switcher and mixer which is able to stream 6-picture PVW or PGM from any one out of the 4 HDMI inputs to any live broadcasting platform via third party live streaming software such as OBS. It adopts compact design, equipped with a 2 inch TFT screen to preview the 4 inputs in real time. 14 transition effects on board work with T-Bar to do transition switching. Along with seamless switching, there are other outstanding features such as audio embedding, de-embedding, and automatically identifying color depth of RGB4:4:4, YUV4:4:4, YUV4:2:2, YUV4:2:0. mini+ adds advanced features including Chroma Key, Logo, PTZ camera control. mini devices are easy to operate either on board or remotely from mobile devices or laptops with XPOSE mini.

## System Connection Diagram



mini /mini+ System Connection Diagram



# Packing Configuration

**Power Adapter**



**USB3.0 Cable**




**Note:**

Power adapter of US/EU standard supplied as standard accessory.


# Hardware Orientation

## Front Panel



<b><u>TFT display</u></b>	To display 4 inputs and menu
<b><u>PUSH/Y</u></b>	<ol style="list-style-type: none"> <li>1. Knob, turn to select menu item, push to confirm</li> <li>2. Work as a quick button to switch HDMI Out between 6-Picture PVW and PGM when TFT is under the state of previewing 4 inputs.</li> <li>3. On mini+, control camera lens position, moving up and down under PTZ control menu-Pos.</li> <li>4. On mini+, control camera lens zoom in and out under PTZ control menu-Zoom.</li> </ol>
<b><u>M( menu)</u></b>	Menu and Back Button
<b><u>S</u></b>	Function Select button, to select Transition effect, Switch Mode (Fast or T-Bar), PIP and FX (reserved licensed feature for future)
<b><u>VOLUME/X</u></b>	<ol style="list-style-type: none"> <li>1. Turn to adjust volume of PGM</li> <li>2. On mini+, control camera lens move left and right under PTZ control menu.</li> </ol>
<b><u>1,2,3,4</u></b>	4 inputs, red is on air (PGM), static green is signal standing by to switch, flash green is the ready to be switched
<b><u>T-Bar</u></b>	Manual switch, push to left end or right end to switch signal to PGM.

# Interface Panel



<b><u>HDMI OUT</u></b>	1 HDMI Output port, connect to display to show Preview (6 pictures) or PGM.
<b><u>HDMI IN</u></b>	4 HDMI Inputs, connect to input source from HD camera or PC
<b><u>DC 12V</u></b>	1 DC Jack for power input, connect to 12V/4A power adapter.
<b><u>LAN</u></b>	Communication port to link dedicated software for control
<b><u>USB</u></b>	USB3.0 output, capture signal via third party streaming software and push to live broadcasting websites
<b><u>AUDIO IN/OUT</u></b>	AUDIO In, analog audio input port, connect to microphone AUDIO OUT, analog audio output port, connect to loudspeaker.

# Use Your Product

## MENU

When mini is power on, the native TFT display show starting up page.



## Main Menu

MAIN		MAIN	
INPUT	>	IP SETTING	>
HDMI	>	LANGUAGE	>
USB3.0	>	RESET	>
AUDIO	>	INFO	>

## Input

Push MENU and select the first menu item <Input>

Push knob to enter <Input> menu

MAIN	INPUT	
	HDMI1: 1920x1080x60	
	HDMI2: 1920x1080x60	
	HDMI3: 1920x1080x60	
	HDMI4: NO INPUT	

## HDMI

Push MENU and select the second menu item <HDMI>

Push knob to enter <HDMI> menu

**HDMI means HDMI output, select Preview output and PGM output for HDMI.**

**Output:** Preview or PGM

**Format:** 1920×1080@60

MAIN	HDMI	
OUTPUT		PREVIEW
FORMAT	1920x1080x60	

## USB3.0

Push MENU and select the third menu item<USB3.0>

USB3.0 means USB3.0 output , push knob to enter <USB3.0>menu, select Preview output and PGM output for HDMI.

**Output:** Choose PGM or Preview

**Format:** 1920×1080@60

MAIN	USB3.0	
OUTPUT		PREVIEW
FORMAT	1920x1080x60	

## Audio

Choose <AUDIO>

**SOURCE:** AFV or Line in choose one of HDMI1,2,3,4

**AUDIO BAR:** ON/OFF

MAIN	AUDIO	
SOURCE		LINE IN
AUDIO BAR		ON




## IP Setting

### SET IP Address Manually

Select each segment with the adjustment knob, then press to enter then set the value of each segment by pressing the knob again.


### Set IP Address Automatically

Use this setting if you network/router has a DHCP server  
Select DHCP and set to ON  
Manual setting is disabled, and the IP Address for mini is set from the network.




## LANGUAGE

LANGUAGE, select Chinese or English



## Factory Reset

Factory Reset: Yes or No



## INFO

Displays the serial number, network and firmware version information


MAIN	INFO	MAIN	INFO
DEVICE SN:		2020XXXXXXXXXXXX	
IP ADDRESS:		192.168.0.100	
MAIN	INFO	MAIN	INFO
MAC ADDRESS:		VIDEO VER:	
18.20.40.96.0a.20		1.10	
MCU VER:			
0.30			

## S Button

Press the "S" button to display and SET features for MIX, MODE, PIP and FX (FX available only on mini+)  
Use the adjustment knob to the left of the S button to move through the settings of each feature, pressing the knob down to adjust and then confirm individual settings.

## MIX

Select the desired transition effect for mixing by using the adjustment knob, and press to confirm the selection.




## MODE

Select from FAST or TBAR switching modes.

In FAST mode switching between sources is done immediately a source (1,2,3,4) key is pressed.

TBAR mode allows a source to be selected for PVW (Preview) with its button, then switched via the TBAR


Set a TIME up to 5sec for transitions, fades or cuts to be used in FAST mode.



## PIP

Display a source as an overlay window. There are both Picture-in-Picture (PIP) and Picture-by-Picture (PBP) presets.

PBP presets are suitable for specialist applications with 2:1 output ration, or with input media that had been specially prepared.



## FX [mini+ only]

CONTROL the attributes of VISCO standard PTZ cameras from mini+ and store position and zoom settings as VIEWS for on demand use.

**CAMERA:** Select a camera to control

**LOAD VIEW:** Recall a saved view for the selected camera

**SAVE VIEW:** Save the control attribute settings for the currently selected camera

**CONTROL:** control and set the attributes of the currently selected camera


**POS:** Set the X & Y (Pan & Tilt)

**ZOOM:** Set the lens zoom factor

**Focus:** Set the focus via Y knob

**ENABLE:** Turn on/off PTZ camera LAN control on mini+

**IP SETTING:** Set the IP addresses for each camera. Note mini+ and cameras must be on the same network subnet.



PTZ		PTZ	Enable
Enable	>	Enable C1	ON
IP SETTING	>	Enable C2	OFF
		Enable C3	ON
		Enable C4	OFF
PTZ		IP SETTING	
		1: 192.168.001.123	
		2: 192.168.001.168	
		3: 192.168.001.165	
		4: 192.168.001.166	

## How to Switch Between Input Sources

Green source buttons are available for switching to output.

A blinking Green source button is the current PVW (preview) source [TBAR mode only]

The source button that is Red is the video source that is the current PGM (program) output

In FAST Mode:

Press a source button (1, 2, 3, or 4) that is green.

Selected source will be switched to the output with the set fade TIME and using the MIX transition selected, with the pressed source button becoming red.

In TBAR Mode:

Press a green button to set the source as the PVW, the source button will blink green.

Slide the TBAR to switch/mix from the current PGM source to the PVW source.. Any MIX transition effect will be applied as the TBAR is moved. Once the TBAR has been fully transitioned, the indicator lights on sources buttons that are PGM and PVW will be swapped.

**Note:** Source selection is locked when TBAR is in transition (not entirely docked at a left or right position)

## How to Apply a PIP

1. Decide which source to be the main picture, select and switch it to PGM when PIP is OFF
2. Select the PIP layout mode in PIP menu, switch A/B layer via the knob.
3. Select the input source and switch it to sub-picture on PGM
4. After switching, the selected green button turns to red.




after PIP mode is selected, the background can not be changed unless turn off the PIP mode and restart the above steps.

# Software Operation

Install dedicated software named XPOSE to control mini or mini+.

Right click the setup exe file .

Choose Run as administrator to open the exe and install the software.




After software is installed, click the icon




XPOSE and login the software.




Click Search to search mini device.







After searching, all available mini devices in the sub-net can be found, up to 128 devices can be found if there are.




Select the desired device by SN and IP and enter the management interface. The software interface is a simulation of operation panel on real mini device.

For example, clicking Button M  can open up menu as on the device. If it is the first time for you to use mini/mini+ we suggest you watch our User Guide video.


Click the drop down arrow and click to play the user guide video.




**INPUT INFO**



**HDMI Output**




**USB3.0 Output**



## MIX


Choose switch time and transition effect.





## PIP

Choose layout mode for PIP



## Live Streaming


Capture Device: choose RGBlink USB3.0 Capture

H.265: When it is ON, users can watch 4 inputs streaming back on XPOSE software.


Import the related OBS application if users need to do live streaming, click Relate to confirm.

OBS: slide on to start streaming.


Note: H.265 and OBS cannot work at the same time. User choose either H.265 or OBS, not both.



## AUDIO



## TEST PATTERN



## HDMI Output Setting

HDMI Out Setting ▲

DVI/HDMI

Bits

Color Space

DE On/Off  Off

DE H Pos

DE V Pos

DE H Size

DE V Size

DE H Polarity  Off

DE V Polarity  Off

## Password Protection


Set password for the device. After password is set, password will be required when enter the software operation interface.

Password Protection ▲

Enable Password  Off


Enter Password

Confirm Password



### IP Setting


Manually set Gateway, MASK and IP for the device.



## FX

On mini+, FX contains 3 features: DSK

Setting, PTZ Camera Control and Logo



## Chroma Key

**Preset:** Customize, black background, red background, blue background, green background, and white background.

**Switch:** On/Off

**Mode:** Select Key In or Key Out.

**Alpha:** The adjustment range is between 0~255.


The color space is R,G,B by default.

The value range of R,G,B is from 0~255

0 means pure white, 255 means pure black.

**Max (Red,Green,Blue):**if users choose any preset mode except customize, the **Max** value of R,G,B is automatically set by system. If users choose customize as Preset, then R,G,B maximum value shall be adjusted manually.

**Min (Red,Green,Blue):**if users choose any preset mode except customize, the **Min** value of R,G,B is automatically set by system. If users choose customize as Preset, then R,G,B minimum value shall be adjusted manually.



## PTZ Camera Setting

Camera: choose camera 1~8

Enable: choose On to enable the LAN communication of the chosen camera.

Zoom: Click + - to Zoom in and out

Focus: Slide Auto to On usually

Brightness: Click + - to adjust

Preset: Load position and zoom setting of camera lens from View 1~20

Save: Save position and zoom setting of camera lens to View 1~20

Pan/Tilt Speed: Adjust the lens moving speed.

Positioner: to adjust the lens left right up down position

OLD IP: the current IP address of the camera

New IP: the new IP address just typed in.

Port: Set port number for PTZ camera. PTZ control support Visca protocol, port number is 1259 by default. mini+ support control PTZ cameras in same IP address with different port number.

Note: Not all cameras can be set IP and port number on XPOSE, for those cameras, IP and port number set can be done on web.

PTZ Camera Setting

Camera: Camera 1

Enable: Off

Zoom: + - Refresh

Focus: + - Refresh

Auto: Off

Brightness: 7

Preset: View 1

Switch

Save: View 1

Save

Pan/Tilt Speed: 14

Positioner

Old IP: 192 168 0 255

New IP: 192 168 0 255

Port: 1080

Set



## Logo

Path: choose logo bin from local computer or U disk.

Color: Adjust Red Green Blue value

Transparent Switch: On/Off

X, Y: adjust logo position

### Logo Overlay

Path

Please select the picture file

Select Picture

Choose Transparent Color

Red  125

Green  125

Blue  125

Transparent Switch  Off

Logo Superposition

1.The image format of the LOGO is a 24-bit bitmap in BMP format. The total size of the image should not exceed 256x128 pixels.  
2.The background should be solid, and the default is white.  
3.The generated files are numbered 1 through 50 and are generated sequentially without interruption.  
4.The generated file is saved in the X3LIVE\LOGO directory on the USB flash drive. If there is no directory, create a new directory.  
5.After the production is completed, insert the U disk into the USB port of the device and import the device through the menu operation.

Switch  Off

X  125

Y  125

Set

### Version Info

Version Info ▲

Software Version	V1.00
MCU Ver	V1.00
Video Ver	V1.00

### T-Bar Calibration

Tbar Calibration ▲

Tbar Calibration  On

Step 1: Push the Tbar to the left side

Step 2: Turn on  Off

Step 3: Push the Tbar to the right side

Step 4: Turn on  Off

Calibration successful!

### Factory Reset

Reset ↺




# OBS Streaming

## OBS Setting

mini is compatible with many third party steaming software, we recommend OBS, which is available to download on <https://obsproject.com/download>. Download the software and update to the latest version.

1.Click "+" icon

2.choose video capture device



3.Click video capture device to open up setting page

4.Choose :RGBlink USB 3.0 Capture

5.Choose Video Format YUY2





If there is no video format YUY 2 after setting above, check the USB 3.0 port connection. Make sure it is linked to USB 3.0port on PC by USB 3.0 cable. (USB 3.0 cable or port is standard in blue while USB 2.0 is in black)




If the captured video is showing mosaic, change the video format to YUY2.

## Audio Setting


When there is no audio playing first check the video source see if the it is set in default value and then check the audio setting on OBS.

1.Set Default for the audio source.




2. Audio setting on OBS.

Choose Audio, click Setting and choose audio device (Mic/Auxiliary Audio Device)




## Streaming Setting

1. Find the RTMP URL and Stream Key provided by streaming broadcast website.
2. Copy URL and Stream Key
3. Back to OBS, click Setting in the lower right corner and click "Stream". Choose Stream Type as "Streaming Service" or "Custom Streaming Server" . If choose "Streaming Service", there is a list of streaming service name available in the drop down list of Service. If the streaming service is in the list, choose it from the list.



If choose Custom Service, just fill in URL and Stream Key.



4. Paste the RTMP URL to Server or URL and Stream Key to Stream Key.
5. Click "Start Streaming".
6. Go back to live broadcast website and check the broadcasting.

# Upgrade

## 1.Tools:



- Firmware ZIP upgrade package
- XTOOL (V1.0.1.10 or higher) -packaged in the ZIP
- Computer with network connection
  - Windows (minimum Win 7, Win 10 recommended)
  - macOS (minimum 10.13 High Sierra)

## 2.Upgrade


2.1 Power on the device connect LAN ports between PC and device by Cat6 cable;

2.2 Ensure that your computer is on the same network as the mini. The default IP address of mini is 192.168.0.99, in which case your computers IP address should be in the range 192.168.0.xxx (xxx cannot be the same as mini or other device on the network) to enable connection between the mini and your computer.


### Check IP of PC:

Step 1. Press  +  keys together to open the Command Prompt


Step 2. In the dialog type: ms-settings:network-status



Step 3. Click on the Properties button



#### Step 4. Scroll down to find your IP address



If the IP address is not in the same section, manual change of IP address is required. Here are the steps:

- Step 1. Click Start menu, click “Setting”
- Step 2. Open **Network and Internet > Network and Sharing Center**.
- Step 3. On the left pane of the new window, click **Change adapter settings**.
- Step 4. You will be displayed with **Network Connections** of the PC.  
**Important note:** Right click on “Ethernet” or “Local Area Connection” if you want to change IP of any physical connection. And right click on “WLAN” in case you wish to change IP of any wireless connections.
- Step 5. Choose **Properties** after right clicking on the network name.
- Step 6. Select the **Internet Protocol Version 4 (TCP/IPv4)**, then click **Properties**.
- Step 7. **Obtain an IP Address automatically** should be selected by default, but please choose the **Use the Following IP Address**.  
Step 8. Now put your desired IP Address according to your wish its correct format. Change **Subnet mask and default gateway** if you want to.

#### Install XTOOL App

Step 1. Extract the Firmware ZIP package into a folder

Step 2. Navigate to the **/Upgrade Tool/XTOOL** folder

Step 3. Right mouse-click the XTOOL Soft Setup and *Run as Administrator* [Windows]

Step 3. Follow the Setup Wizard to install all the components. There will be multiple Dialog windows pop-up for installing the necessary components (*refer XTOOL Installation Guide*)

If the XTOOL app has been installed previously, use the **Modify** option to complete the setup.


XTOOL is a universal updater application for RGBlink products, as such has a number of features in support of the full range of RGBlink devices that are not utilised for mini updates in this guide

#### 1. Upgrade

Open the XTOOL app with *Run as Administrator* [Windows]

## Connect to mini

Step 1. Click on **Connection**




Step 2. check the **Net Comm** option box

Step 3. enter the IP Address of the mini (as example above, default mini IP is 192.168.0.99)  
remember computer and mini **MUST** be on the same subnet


Step 4. click **Confirm**

Step 5. Review Connection Status at bottom left, to confirm indicator light is green and there is device information showing at bottom right



## Load the Firmware Update File

Step 1. Click Choose File




Step 2. Navigate to the package folder and select the MiniPackage .bin file

### **Set Components to Update**

Click the Select All check box which will enable all components to be updated to the latest versions


Advanced updating allows single component upgrading






## Upgrade

Step 1. Click **Upgrade**




Step 2. Monitor the progress


DO NOT DISCONNECT OR POWER DOWN while updating



Step 2. Following update click **Confirm** in the pop-up window



Step 3. Click Version to refresh, then review the main window to confirm upgrade versions now match



### Finish

Step 1. Close XTOOL

Step 2. Disconnect mini

Step 3. mini is now upgraded and ready to use

# Contact Information

## Warranty:

All video products are designed and tested to the highest quality standard and backed by full 1 years parts and labor warranty. Warranties are effective upon delivery date to customer and are non-transferable. RGBlink warranties are only valid to the original purchase/owner. Warranty related repairs include parts and labor, but do not include faults resulting from user negligence, special modification, lighting strikes, abuse(drop/crush), and/or other unusual damages.

The customer shall pay shipping charges when unit is returned for repair.

**Headquarter:** S601~609 Weiye Building Torch Hi-Tech Industrial Development Zone Xiamen, Fujian Province,  
P.R.C

- **Tel:** +86-592-5771197
- **Fax:** +86-592-5788216
- **Customer Hotline:** 4008-592-315
- **Web:**
  - ~ <http://www.rgblink.com>
  - ~ <http://www.rgblink.cn>
- **E-mail:** [support@rgblink.com](mailto:support@rgblink.com)

